

Notus EPFR-609

Fire Retardant Epoxy Prepreg System



DESCRIPTION

Notus EPFR-609 is a market leading fire-retardant epoxy prepreg system that combines exceptional FST performance with user-friendly handling characteristics and a long out life.

EPFR-609 is ideal for small to very large structural parts that require a Tg in the range of 100 to 120°C. It can be cured at temperatures from 85 to 120°C and is suitable for low pressure/vacuum curing processes. Notus EPFR-609 has a very long out life at room temperature (60 days at 21-23°C) and can be kept frozen for up to 18 months at -18°C.

Notus has carried out extensive testing, with EPFR-609 complying with FAR 25.853 and NFPA 285 as well as ASTM E84 Class A and UL94 V0.

Controlled resin flow and high peel strength on honeycomb cores mean EPFR-609 is well suited to sandwich structures as well as monolithic laminates. EPFR-609 is available in all prepreg and N1-Preg formats and can also be supplied as a supported resin film.

FEATURES AND BENEFITS

- Exceptional fire performance, passes NFPA 285 and Class A for ASTM E84 (with NE11FR film).
- · Low exotherm risk, even for thick laminates.
- Long out-life & shelf-life.
- High strength bonding with honeycomb and foam cores.

APPLICATIONS

EPFR-609 is the perfect choice for Architecture, Aerospace, Rail and other Industrial sectors where reaction to fire and low smoke toxicity are required.

CURE SCHEDULE


Minimum cure requirements

Property	Result	Test Method
Minimum cure temperature (°C)	90	DSC
Cure time (hours:mins) at min temperature	6:00	DSC
Glass transition temp, Tg (°C)	98	DSC




RHEOLOGY

Rheology profile for EPFR-609 prepreg system



Typical vacuum curing schedule for EPFR-609 prepreg system





CURED MATRIX PROPERTIES

(85°C for 30 Minutes & 120°C for 90 Minutes)

Property	Result	Test Method
Tensile Strength (MPa)	57	ISO 527
Tensile Modulus (GPa)	4.5	ISO 527
Flexural strength (MPa)	98	ISO 178
Flexural Modulus (GPa)	5.3	ISO 178
Density (g/cc)	1.46	ASTM D 792
Glass Transition Temp(°C)	111	DSC

LAMINATE PROPERTIES

Typical Mechanical Properties of EPFR-609 Prepreg (H-glass UD 600gm, 50% RC)

Property	Test Standard	Result
Tensile strength (MPa)	ISO 527	1022
Tensile modulus (GPa)	ISO 527	48
Flexural strength (MPa)	ISO 14125	1164
Flexural modulus (GPa)	ISO 14125	47
Compression strength (MPa)	ISO 14126	977
Compression modulus (GPa)	ISO 14126	39
Inter laminar shear strength (MPa)	ISO 14130	53

Typical Mechanical Properties of EPFR-609 Prepreg (8 harness woven glass 300gm, 30% RC)

Property	Test Standard	Result
Tensile strength (MPa)	ISO 527	460
Tensile modulus (GPa)	ISO 527	23
Flexural strength (MPa)	ISO 14125	650
Flexural modulus (GPa)	ISO 14125	25
Compression strength (MPa)	ISO 14126	490
Compression modulus (GPa)	ISO 14126	23
Inter laminar shear strength (MPa)	ISO 14130	49



REACTION TO FIRE TESTING RESULTS

NFPA 285 - EPFR-609 prepreg (E-glass triax 750gm, 50%RC) with NE11FR film¹
Satisfies all horizontal and vertical flame spread criteria and thermocouple temperature limits - Pass

ASTM E84 - EPFR-609 prepreg (E-glass triax 750gm, 50%RC) with NE11FR film¹

ASTM E84 test result class	Class A
Flame spread index	5
Smoke developed index	200

 $^{^{\}scriptscriptstyle 1}$ NE11FR was formerly known as FR Film 609.

FAR 25.853

Satisfies all fire, smoke and toxicity criteria - Pass

Test	Parameters / Test Condition	Results
Flammability	Extinguishing time	Nil – did not ignite
	Burn length	Nil – did not ignite
	Drip extinguishing time	No dripping
Smoke Density at 4 minutes	With pilot flame	28.79
	Without pilot flame	23.9
CO Toxicity – ppm at 4 minutes	With pilot flame	376
	Without pilot flame	239

FAR 25.853 Toxicity concentration measurements in ppm at 4 minutes


Toxin	со	NO/NO2	HCN	HCI	HF	S02	HBr
FAA Requirements	<1000	<100	<150	<150	<100	<100	-
EPFR-609 results	376/239	0.9/0.4	7/5	0	0	0	0
Comments	Pass	Pass	Pass	Pass	Pass	Pass	Pass



PROCESSING METHOD

- Take the prepreg roll out of sealed plastic bags.
- Cut the prepreg to the desired size on a cutting table.
- Pull off the protective polyethylene film and lay the prepreg onto the mould. If multiple layers are required, pull off protective film and lay prepreg layers one on top of each other. Make sure that a roller is applied to each layer to avoid any wrinkling or air voids between layers.
- When the desired thickness or lay-up is completed, make the vacuum bag on the mould to cover the entire laminate and apply vacuum.
- Apply full vacuum (approx. 760mm Hg) for 10 minutes before starting the heated cure cycle
- When all air is removed, place the mould in the oven or turn on heat source.
- Complete the cure cycle (as per the defined cure cycle chart).
- After completing the cure cycle, turn off the heat source whilst maintaining vacuum pump pressure.
- Turn off the vacuum pump only when part temperature has dropped to 60°C or below.
- After turning of the vacuum pump, the part can be removed from the mould.

Typical Vacuum Bagging Arrangement





TRANSPORTATION, HANDLING AND STORAGE

EPFR-609 prepregs should be kept in the original packaging during transport and storage. Transport should be at -18°C to maximise the life of the product. EPFR-609 prepregs should be stored, wrapped and sealed in polythene, at -18°C for maximum shelf life.

Temperature	Maximum Storage Time
-18°C	18 months
21°C	60 days

The material must be fully thawed before breaking the polythene seal to avoid moisture contamination.

Handling of the prepreg should be at a clean area where relative humidity is ≤ 55% and ambient temperature is 20-23°C.

Only take out the quantity required for immediate production usage, the remaining material should be wrapped up and sealed and returned to the freezer. This will extend the shelf life of the EPFR-609 prepreg.

The backing film should be removed from the EPFR-609 prepreg only when it is ready to be laminated or positioned in the mould. Remove the backing film from the side which is going to touch the mould surface. Remove the remaining backing film only when the next prepreg layer is ready to be placed

HEALTH AND SAFETY PRECAUTIONS

Prepregs are low risk in terms of handling hazards, however, the usual precautions should be applied. Gloves and protective clothing should be worn.

To avoid eye contamination, safety glasses should be worn. In the case of any contamination, eyes must be flushed for 15 minutes with clean water and a doctor should be consulted or further medical advice should be sought. Use mechanical exhaust ventilation when heat curing the EPFR-609 product.

Hands and contaminated skin must be cleaned properly with soap and warm water after finishing work.

NOTICE AND DISCLAIMER

Information supplied by Notus Composites in this document is based on representative samples. As the handling conditions and methods are critical to the material performance, the company strongly recommends that customers make test panels and conduct appropriate testing of any goods or materials supplied by Notus to ensure that they are suitable for the customer's intended application. The company specifically excludes any warranty of fitness for purpose of the goods other than as provided in writing by the company.

All advice, instruction or recommendation is given in good faith but the company only warrants that advice in writing is given with reasonable skill and care. No further duty or responsibility is accepted by the company. All advice is given subject to the Terms and Conditions of Sale which are available on the website or on request from the company. Notus Composites continuously reviews and updates its technical and marketing literature. Please ensure that you are working with the most current version which can be checked by contacting your Notus sales or technical support contacts

CONTACT

Notus Composites FZC, P.O Box 38124, Shed 26 Warehouse 8,9 & 10, RAK FTZ Technology Park, Ras al Khaimah, U.A.E Tel: +971 50 531 2552 Email: info@notuscomposites.com Web: www.notuscomposites.com